

# S-1000 MP (MULTI-PURPOSE) THIN SET LATEX MORTAR

**PRODUCT DESCRIPTION:**

S-1000 MP is a high quality multi-purpose thin set mortar formulated with a special powdered latex designed to provide superior bond and shear strength, freeze-thaw resistance, impact-resistance, and reduced water absorption. The non-reemulsifying resin system in S-1000 MP also provides excellent workability. S-1000 MP meets or exceeds ANSI A118.1, A118.4 and A118.11. S-1000 MP is available in #910 White and #960 Gray.

**USES:**

S-1000 MP multi-purpose thin set is recommended for setting all types of ceramic tiles, marbles, slate and granite. S-1000 MP is recommended for interior or exterior wall or floor applications.

**LIMITATIONS:**

High temperature or low humidity will reduce open time up to 15 minutes. All traffic should be kept off tile for 48 hours when used as a floor mortar. Grouting operations should not be performed less than 24 hours after setting when used as a wall mortar.

When installing porcelain pavers over plywood, flooring must be exterior-grade plywood that meets all ANSI guidelines. Floor deflection cannot exceed "L-over-360" under both dead and live loads.

**TECHNICAL DATA: Physical Properties:**

Shear bond strength	
after 20 freeze/thaw cycles	
Wall tile, psi	350
Ceramic mosaics, psi	325
Shear bond strength	
Ceramic mosaics, psi 7 day, dry	300
Ceramic mosaics, psi 7 day, in water	200
Ceramic mosaics, psi 28 day, dry	375
Ceramic mosaics, psi 7 day, in water	
(no prior dry cure)	150
Quarry to Plywood, psi 7 day, dry	160
Quarry to Plywood, psi 28 day, dry	180
Sag using 4" x 4" x 5/16" ceramic mosaics tile, in.	.000
Open time of up to 30 minutes.	
Pot life approximately 80-90 minutes.	

**INSTALLATION:**

Substrates: All substrate preparation and tile installation must be in accordance with the Tile Council of America's Handbook for ceramic tile installations to insure proper performance and longevity of the installation. Substrates include cured concrete, mortar bed, wood subfloor with mortar bed substrate, exterior grade plywood, dry wall, glass mesh mortar units and masonry.

Mixing: S-1000 MP should be mixed with clean, cool potable water only. Add enough water to S-1000 MP to give it a paste like consistency which is easy to trowel but will hang on an inverted trowel. Mix using a *slow* speed revolving bucket type mixer or a similar mixer. *Do not mix at high speed.* Remix after slaking for the appropriate time (normally 5 to 10 minutes) and add more water or S-1000 MP powder if necessary.

**APPLICATION:**

Trowel only that area which can be set in 15-30 minutes, taking temperature and humidity into consideration. Extremely high

temperatures or low humidity, however, can reduce the open time by up to 15 minutes. The pot life of this product is approximately 80-90 minutes.

**SETTING:**

Full coverage of the setting material on the back of the tile is desirable to prevent broken and cracked tile. The National Tile Contractors Association recommendation to accomplish full coverage is as follows: Apply mortar to substrate using the flat side of the trowel to fill any voids and "key" the material to the substrate. Using the proper sized notched trowel, comb the mortar evenly in one direction only. Do not "swirl". Set the tile in the mortar with the edge of the tile parallel to the comb lines. To remove air voids, push the tile back and forth in the mortar perpendicular to the comb lines.

**CAUTION:**

JOB FAILURES CAN OCCUR FROM SETTING TILE ONTO THIN SET WHICH HAS "SKINNED". Check any mortar which has been on the substrate any longer than 10 minutes by pressing a tile lightly but firmly onto the trowelled ribs of mortar. If proper coverage isn't obtained, recomb the mortar and retest, or remove and trowel new material. ALL TRAFFIC SHOULD BE KEPT OFF THE TILE FOR 48 HOURS WHEN S-1000 MP IS USED AS A FLOOR MORTAR AND GROUTING SHOULD NOT BE PERFORMED LESS THAN 24 HOURS AFTER SETTING WHEN USED AS A WALL MORTAR.

**PROTECTING NEW TILEWORK:**

To avoid damage to finished tilework, schedule floor installations to begin only after all structural work, building enclosure, and overhead finishing work, such as ceilings, painting, mechanical and electrical work are completed. Keep all traffic off of finished tile floors until it has fully cured, or provide up to 3/4" thick plywood protection over Kraft paper to protect floors before installation materials have fully cured.

**COVERAGE:**

Sq. Ft./lb. at 3/32" to 1/8" bed thickness 2.0-2.5

**CLEAN-UP:**

Clean spills and tools with water. (Warm water with a small amount of detergent will expedite clean-up operation.)

**COLORS:**

#910 White and #960 Gray.

**PACKAGING:**

S-1000 MP multi-purpose thin set mortar is available in 25 lb. and 50 lb. bags.

**SPECIFICATIONS:**

Material: Thin set latex mortar for setting ceramic tile on vertical and horizontal surfaces shall be S-1000 MP, consisting of Type I portland cement, specially graded silica aggregates (#7 on M.O.H. Scale of Hardness), water retention aid and anti-sag and anti-skinning aids, and a specially blended dry latex with protective colloids; as manufactured by Summitville Tiles, Inc., Summitville, Ohio. Material shall meet or exceed ANSI A118.4 and ANSIA118.11.

Color: Color shall be # \_\_\_\_\_.



Summitville Tiles Inc. • Summitville, Ohio 43962  
(330) 223-1511 • FAX (330) 223-1414  
www.summitville.com

